


## DISASSEMBLY


### 1. TILT/SWIVEL REMOVAL

- 1) Set the monitor face downward.
- 2) Pressing the latch (a), carefully remove the Tilt/Swivel by pulling it upward.




### 2. BACK COVER REMOVAL

- 1) Remove four screws (a) from the Back Cover.
- 2) Slide the Back Cover away from the Front Cabinet of the monitor.




### 3. SPEAKER ASS'Y REMOVAL

- 1) Remove four screws (a).
- 2) Disconnect P802 and P4.
- 3) Remove the Speaker Ass'y.




#### 4. TOTAL CHASSIS ASSEMBLY REMOVAL

- 1) Disconnect P901 (Degaussing pin), P701 (DY pin), P502 (Tilt pin), and P501 (Purity pin) from the Main PCB.
- 2) Disconnect P401.
- 3) Carefully separate the CDT Board Assembly from the CDT neck.
- 4) Discharge the remaining static electricity by shorting between the Anode Cap and the CDT ground.
- 5) Disconnect the Anode Cap from the CDT.
- 6) Remove five screws (a).
- 7) Remove the Total Chassis Assembly from the Main Frame.




## 5. VIDEO PCB ASSEMBLY REMOVAL

- 1) Remove four screws (a).
- 2) Disconnect P301, P302, and Pin (b).
- 3) Remove the Video PCB Assembly.



## 6. METAL REAR & ASS'Y REMOVAL

- 1) Remove eight screws (a).
- 2) Disconnect P1, P2, P3 and P805.
- 3) Carefully remove the Interface Assembly and Metal Rear from the Main Total Ass'y.



## 7. MAIN BRACKET REMOVAL

- 1) Remove ten screws (a).
- 2) Remove the Rear Bracket.
- 3) Release three latches (b), and remove the Bottom Bracket.

